
IMPORTANT: Read before Using

PREXISO



PTL10

www.prexiso-eu.com

30FT (10M)* LASER LEVEL AND SQUARE

2 VEARS

A SAFTETY INSTRUCTIONS

Working safely with the measuring tool is possible only when the operating and safety information are read completely and instructions contained herein are strictly followed. Never make warning labels on the measuring tool unrecognizable. SAVE THESE INSTRUCTIONS.

Caution – The use of operating or adjusting equipment or the application or processing methods other than those mentioned herein, can lead to hazardous radiation exposure.



LASER RADIATION. Do not stare into beam. Class II laser product. Turn the laser beam on only when using this tool.

- Do not remove or deface any product labels.
- Avoid direct eye exposure. The laser beam can cause persons being blinded.
- Do not operate the tool around children or allow children to operate the tool.
- **Do not** place the tool in a position that may cause anyone to stare at the laser beam, whether intentionally or unintentionally.
- **Do not** use on reflecting surfaces such as sheet steel, glass or polished metal etc. that have shiny, reflective surfaces. The shiny surface could reflect the beam back at the operator.
- Always turn the laser tool off when not in use. Leaving the tool on increases the risk of someone inadvertently staring into the laser beam
- Do not attempt to modify the performance of this laser device in any way. This may result in a dangerous exposure to laser radiation.
- Do not attempt to repair or disassemble the laser-measuring tool. If unqualified persons attempt to repair this product, serious injury may occur. Any repair required on this laser product should be performed only by qualified service personnel.
- Use of other accessories that have been designed for use with other laser tools could result in serious injury.

- Do not operate the tool outdoors.
- Do not place or store tool under extreme temperature conditions
- Do not operate the tool in explosive environments, such as in the presence of flammable liquids, gases or dusts. Sparks can be created in the tool which may ignite the dust or fumes.
- Keep the tool away from cardiac pacemakers. The magnet inside the tool generates a field that can impair the function of cardiac pacemakers.
- Keep the tool away from magnetic data medium and magnetically-sensitive equipment. The effect of the magnetic can lead to irreversible data loss.
- Measurement may not be accurate if used beyond the rated range of the device.
- The use of optical instruments with this product will increase eye hazard.
- Always make sure any bystanders nearby aware of the dangers of looking directly into the measuring tool.
- Do not use the laser viewing glasses as safety goggles, they do not protect eyes against laser radiation.
- Always remove the batteries when cleaning the laser light aperture to laser lens.

TECHINICAL SPECIFICATIONS


COMPONENT	SPECIFICATIONS
Laser	λ=620-690nm, Class II laser, maximum laser output<1mW
Operating range (typically)	30FT (10M)*
Accuracy (typically)	±3/8IN@30FT (±1mm@m)*
Estimated battery life	10 hours (alkaline batteries)
Optimum operating temperature	32°F to 104°F (0°C to 40°C)
Storage temperature	14°F to 140°F (-10°C to 60°C)
Batteries	2 x 1.5V alkaline AA

*Important: The accuracy is rated within distance of 10 meters. Under unfavorable conditions, such as in extreme interior illumination, transparent surfaces (eg. glass, water), porous surfaces (eg. insulation materials) or reflecting surfaces (eg. polished metal, glass) or very rough surfaces (eg. rough cast, natural stone), the tool's measuring range and accuracy will be reduced.

DESCRIPTION

KNOW YOUR LASER LEVEL AND SQUARE

This is a highly versatile tool. It can be placed on the ground, mounted on a door frame, work bench etc. • An accuracy of ±3/8IN@30FT (±1mm@m). • AA alkaline batteries.



PARTS	DESCRIPTION
А	Power button
В	Laser aperture
С	Leveling vials
D	90° layout guide
E	Battery compartment lid
F	Battery compartment latch
G	Magnets
Н	Leveling plate
	Lock holes in the leveling plate
J	AA batteries

UNPACKING

When unpacking the box, do not discard any packing materials until all of the contents are accounted for:

- Laser level and square
- 2 x AA alkaline batteries
- Leveling plate
- Operator's manual

Carefully lift the laser tool out of the package and place it on a stable, flat surface.


ASSEMBLY

INSERTING/REPLACING THE BATTERY

AA alkaline batteries are recommended for the measuring tool. To open the battery compartment lid, press the latch and remove the battery lid. Insert the batteries provided. Pay attention to the correct polarity of the batteries according to the representation on the metal plate inside the lid.

Always replace all batteries at the same time. Only use batteries from one brand and with the identical capacity.

NOTE: Remove the batteries from the tool when not using it for extended periods. When storing for extended periods, the batteries can corrode and discharge themselves.



OPERATION

1. TO TURN THE LASER TOOL ON AND OFF

The power button is located on the top of the tool housing. To turn on the tool, press the power button once briefly. Immediately after turning on, the tool projects the two laser line 90° from the laser aperture.


WARNING: When turning on the tool laser, always be aware of protecting your eyes and the eyes of those around you. Never point the laser at anyone's face, including your own.

2. USING WITH THE LEVELING PLATE

The leveling plate allows the tool to work in various applications. Such as on a wall, an inclined surface etc.

a. Fix the leveling plate on a wall or inclined surface using e.g. Standard screws. Use a level to fix the leveling plate flat on the surface.

b. Position the tool with the magnets on the underside on the leveling plate.



3. APPLICATIONS

The tool can be placed on the ground, mounted on a work bench / door frame etc. for point marking and simple alignment by sight, It is ideal for the following applications:

- Laying tile and flooring
- Checking right angles
- Wallpapering and stencil work
- Framing doors and windows
- Installing electrical wiring and pipes
- Mounting wall fixtures, electrical outlets, switches and lighting
- Installing a drop ceiling
- Painting
- Installing cabinets

MAINTENANCE

This compact laser measuring tool has been designed to be a low-maintenance tool. However, in order to maintain its performance, you must always follow these simple directions:

- Avoid exposing the tool to shock, continuous vibration or extreme hot or cold environment.
- Always store the tool indoors.
- Always keep the tool free of dust and liquids. Use only a clean soft cloth for cleaning. If necessary, slightly moisten the cloths with pure alcohol or a little water.
- **Do not** disassemble the compact laser measuringtool, this will expose the user to hazardous radiation exposure.
- Do not attempt to change any part of the laser lens.

TROUBLESHOOTING

PROBLEM	CAUSE	SOLUTION
The laser line projection is weak.	Batteries are weak.	Replace with new batteries.
The laser line is hard to see.	The tool is out of the rated operating range	Move the tool closer to be within the rated operating range.
Laser line is not projected.	No batteries installed or batteries are depleted.	Install new batteries.
Laser line flickers for alert.	The surface where the tool has been placed is uneven or the tool is out of its automatic self-leveling range.	Place the tool on flat surface levels within +/-4 degrees.

WARRANTY

The Prexiso PTL10 has a two-year warranty. For further information on this, contact your dealer.

This warranty is void if product is used for commercial purposes. This warranty is not transferable and does not cover products damaged by misuse, neglect, accident, alterations or use and maintenance other than that specified in the owner's manual. This warranty does not apply to any expendable parts that can wear from normal use. This warranty excludes any accessories.

Printed in China